

Appendix A: Additional spare parts

Some of the spareparts shown on the ISO-metric drawings in Part 1 have no sparepart number and specification. The sparepart numbers and specification for those parts are listed below. The page and position numbers refer to the page and position numbers used in Part 1.

When ordering spare parts please state carefully the spare part number, the specification and the number of items wanted before you send your order.

Pos.No	68	85	Specification	
Page 1-2 (Panels):				
1	10065477	10065477	PANEL, FENDER, RIGHT, POLYMER	
2	10065478	10065478	FENDER, LEFT	
4	70349	70344	PANEL, TOP, HINGED	
9	10012863	10012861	COVER, DRYER	
Page 1-4 (Stand):				
1	10065466	10065480	PANEL, FRONT, STAND	
3	10065468	10065468	RAIL, STAND	
6	10065464	1006582	PANEL, REAR, STAND	
Page 1-6 (Stand, closed):				
3	10065473	10065473	PANEL, SIDE, LEFT, STAND	
4	10065475	10065475	PANEL, RIGHT, STAND	
Page 1-18 (Pump / circulation):				
18	15770	15770	INSERT, FILTER 50MY	
Page 1-32 (Developer)				
11	85745	85296	BRUSH, D40, WITH GEAR, PP 0.10	(WHITE BRUSH)
	10001483	10001482	BRUSH, D40, WITH GEAR, PP 0.075	(BLACK BRUSH)